



DIY CHICKEN WATERER

1

CLEAN AND EMPTY A 5-GALLON BUCKET

2

DRILL TWO 1-INCH HOLES OPPOSITE OF EACH OTHER ALONG THE BOTTOM EDGE OF THE BUCKET

3

PLACE THE BUCKET INSIDE A FOIL ROASTING PAN (RIGHT-SIDE-UP)

4

FILL IT WITH CHICKEN WATER

5

REPLACE THE LID, IT HAS TO BE AIRTIGHT SEALED

6

THE WATER WILL STOP ONCE THE WATER COVERS THE HOLES COMPLETELY